GEBWELL

QUICK GUIDE - GRUNDFOS UPM3(K) DHW

PUMP SETTINGS

Select the pump settings according to the operating environment.
Select constant curve 1, 2 or 3 as a control mode.

	OPERATING PANEL	CONTROL MODE
1		Constant curve 1 – PWM signal off
2		Constant curve 2 – PWM signal off
3		Constant curve 3 – PWM signal off

TROUBLESHOOTING

ALARM STATUS	FAULT
	BLOCKED
	LOW VOLTAGE
	ELECTRICAL ERROR

FAULT	DISPLAY	SOLUTION	
OFF 0 V			**Pump does not function, no power.** Check that: **A** the power plug is plugged in, **B** the switch is turned on.
ON 230 V			**1. The LED is lit – An axle or impeller is stuck.** To release the axle/impeller, press on the screw in front of the pump and turn it using a screw driver.
ON <160 V			**2. The LED is lit – Supply voltage too low** Check the supply voltage.
ON 230 V			**3. The LED is lit – Supply voltage too low, severe malfunction** Check the supply voltage. Replace the pump.