

***GEBWELL***

## Gebwell Concept – PI diagram configurator

- Creates heat pump -/district heating PI diagrams based on user choices
- Rules and diagram templates are loaded from network (automatic update on start-up)
- Runs offline after first use if needed

## Loading application to computer

- Register account at [www.gebwell.fi/en/gebwell-concept/](http://www.gebwell.fi/en/gebwell-concept/)
- Load Configurator client at [www.gebwell.fi/en/gebwell-concept/](http://www.gebwell.fi/en/gebwell-concept/)
- Save and run Setup.exe. Application is ready for use.
- All users have access to limited demo versions of the tools.  
*Contact [conceptsupport@gebwell.fi](mailto:conceptsupport@gebwell.fi) to get access to full versions.*
- If you have problems registering or downloading an application, contact [conceptsupport@gebwell.fi](mailto:conceptsupport@gebwell.fi)

## Register your account at [www.gebwell.fi/en/gebwell-concept/](http://www.gebwell.fi/en/gebwell-concept/)

- Click [Register](#) and fill out the form
- *NOTE! Password requirements:*
  - *Min length 6*
  - *digit (a number)*
  - *non-alphanumeric character (i.e. special character)*
  - *uppercase letter*
  - *lowercase letter (e.g. Pass!1)*

The screenshot shows the registration page for GEBWELL. At the top, there is a navigation bar with 'Home', 'Register', and 'Log in' links. The main heading is 'Register', followed by the sub-heading 'Create a new account'. A note states 'Fields marked with \* are required.' The form includes the following fields: 'First name \*', 'Last name \*', 'Company \*', 'Region \*', 'Title', 'Phone number', 'Email \*', and 'Password \*'. Below the password field, there is a list of password requirements: 'Min length 6', 'Require digit (a number)', 'Require non-alphanumeric character (i.e. special character)', 'Require uppercase letter', and 'Require lowercase letter'. There is also a 'Confirm password \*' field. At the bottom of the form, there is a checkbox for 'I have read and accept the Terms of Use \*' and a 'Show Terms of Use' link. A 'Register' button is located at the bottom of the form. The footer of the page contains the copyright notice '© 2018 - Gebwell Concept™', the GEBWELL logo, and a language selection dropdown set to 'English (United Kingdom)'.

## Confirming e-mail address and downloading application

- You will be sent an e-mail and asked to confirm the e-mail address given at the registration. Click on the **email confirmation link** on the e-mail body.
- On the web page that opens on the click, you are able to download the application on your computer by clicking the link: Download Gebwell Concept via this link

### Confirm email

Thank you for confirming your email to Gebwell Concept.

Download Gebwell Concept via [this link](#).

© 2018 - Gebwell Concept™



- Click Install on the next page and the application will download
- Concept application needs .NET Framework version 4.7.1 or later to work. .NET Framework can be loaded from Microsoft <https://www.microsoft.com/en-us/download/details.aspx?id=56115>

- You can also download the application at: [www.gebwell.fi/en/gebwell-concept/](http://www.gebwell.fi/en/gebwell-concept/)
- Click [Download](#)
- Concept application needs .NET Framework version 4.7.1 or later to work. .NET Framework can be loaded from Microsoft <https://www.microsoft.com/en-us/download/details.aspx?id=56115>

## Once downloading is complete


- Run loaded Setup.exe
- Application is ready for use.

## Changing Password

- If you have forgotten your password or want to change it click <https://concept.gebwell.fi/newConfigurator/Account/ForgotPassword>
- Give e-mail address you gave on registration.
- Program will send a reset password link to your E-mail.
- *NOTE! Password requirements; Min length 6, digit (a number), non-alphanumeric character (i.e. special character), uppercase letter, lowercase letter (ex. Pass!1)*


## Starting configurator


- Click Gebwell Concept Client shortcut on your desktop
- Click Run on popup window
- At first start-up application asks your username (E-mail), password and acceptance of terms of use
- Update matrices and dictionary (choose tool you want to update and click Update)





# Changing language of configurator

- Language used in configurator can be changed
- Open configurator settings by clicking setup icon on upper right corner   
Choose the desired language in the pop-up window




- When ready Save settings and **restart** configurator


- Select the desired tool from the drop-down menu on the top left corner and the form will open.

The screenshot shows the 'Gebwell Concept™' software interface. At the top left, the 'CONFIGURATOR' title bar contains a dropdown menu labeled 'Tool Selection' with 'Heat pump configurator' selected. This menu is circled in red. To the right of the dropdown is 'Version 8'. In the top right corner, there are 'ONLINE' and 'Settings' icons. Below the title bar, the 'Commons' section contains a list of 'Number of Heat pumps in system' (1, 2, 3, 4) with a 'Clear' button, and a 'Remote access' section with 'Yes' and 'No' options. The '1st Heatpump' section includes 'Is DHW produced by heat pump system?' with 'Yes' and 'No' options, and a 'Room unit' section with 'Yes' and 'No' options. At the bottom, there are 'Load configuration...', 'Save configuration...', and 'Flow through immersion heater' options. A status bar at the bottom right shows 'Selections: 0 / 68' and 'Reset' and 'Finish' buttons. The 'GEBWELL' logo and 'Gebwell Concept™' text are visible at the bottom of the window.


- Make choices in form
- Green marking on upper left corner of group/category tells that Selection is made or category is filled.
- When category is filled completely, it will automatically be minimized. The category can be restored from the arrow in the upper left corner of the partition.
- To clear the selection, click the Clear link located at the bottom right of the dialog box.



- Available options on dialog boxes are bolded.
- Option that can't be used is shown grey cursive text.
- Filled category is automatically minimized. If needed category can be restored by clicking arrow on left of the category title.




- After completing all categories, click Finish at the lower right corner.



*Note! All selections can be cleared (to reset the form) by Reset button*

*Configuration can be Saved and loaded by [Save configuration](#) and [Load configuration](#) -links*

- Diagram opens at CAD-tab. Now location, designer, and other details can be added.
- Save-button saves configuration and diagram in pdf- and dwg- format in desired location.
- If selections needed to be changed, go back to Configurator –tab.
- If tool has more than one diagram, diagrams are listed under the Configurator/Diagram bar.



The screenshot shows a configuration form with the following fields and options:

- Refresh** button (top right)
- Location, row 1**: Text input field
- Location, row 2**: Text input field
- Desinger**: Text input field
- Date**: Text input field with value '10/07/2018'
- Offer number**: Text input field
- Options** (checkboxes):
  - Create PDF
  - Use black and white
  - Save configuration
- Save** button (red)
- Zoom** controls:  **100%**  (red buttons)

## Gebwell Ltd. Contact information



**Gebwell Ltd.**

Patruunapolku 5, FI-79100 Leppävirta, FINLAND

Tel. +358 20 1230 800 | [info@gebwell.fi](mailto:info@gebwell.fi)